



02.  
01.

천수막걸 (PLACARD BATTEN)  
광주막걸 (APRON LIGHT)
00.  
01.  
02.  
03.  
04.

영점선 (ZERO LINE)  
만막 (HOUSE CURTAIN)  
조명용 1 (#1 LIGHT BATTEN)  
조명용 2 (#2 LIGHT BATTEN)  
장제용 1 (#1 SET BATTEN)
05.  
06.  
07.  
08.  
09.  
10.  
11.  
12.

천장광반사판 1 (#1 ACOUSTICAL SHELL-CEILING)  
조명용 2 + 머리대 1 (#2 LIGHT BATTEN + #1 HOUSE BORDER)  
천장광반사판 2 (#2 ACOUSTICAL SHELL-CEILING)  
천장광반사판 3 (#3 SET BATTEN)  
천장광반사판 4 (#4 SET BATTEN)  
광사 (SCREEN)
13.  
14.  
15.  
16.  
17.  
18.  
19.  
20.  
21.  
22.

장제용 4 (#4 SET BATTEN)  
장제용 5 (#5 SET BATTEN)  
천장광반사판 2 (#2 ACOUSTICAL SHELL-CEILING)  
조명용 3 + 머리대 2 (#3 LIGHT BATTEN + #2 HOUSE BORDER)  
장제용 6 (#6 SET BATTEN)  
천장광반사판 34 (#34 ACOUSTICAL SHELL-SIDE WALL)  
천장광반사판 35 (#35 ACOUSTICAL SHELL-SIDE WALL)  
장제용 7 (#7 SET BATTEN)  
하늘막상단 조명 + 머리대 3 (UPPER CYC. LIGHT + #3 HOUSE BORDER)
23.  
24.  
25.

장제용 8 (#8 SET BATTEN)  
하늘막 (CYCLORAMA)
26.  
27.  
28.  
29.

커넥터박스 1 (#1 CONNECTOR BOX)  
커넥터박스 2 (#2 CONNECTOR BOX)  
커넥터박스 3 (#3 CONNECTOR BOX)  
커넥터박스 4 (#4 CONNECTOR BOX)